

THETA DIGITAL

Casablanca III HD Owners Manual Addendum

RS232 Protocol and Control Details

This document applies to Casablanca III HD (only) with software version 4xx.

When linking commands, please put a mute-volume command then a 10 second delay between the turn-on command and the first input-select command.

(Inputs 1, 2 and 3 have hidden menu which will be opened if there is no delay.)

RS232 Hardware Connections

RTS and CTS are not implemented in the Casablanca III

DB9


Pin	I/O	
1 - DCD	0	Jumped
2 - Casablanca III sends on this pin	0	
3 - Casablanca III receives on this pin	1	
4 - DTR	1	
5 - GND		
6 - DSR	0	
7 - RTS	1	
8 - CTS	0	
9 - Ring	---	

CN2


RJ45

Pin	I/O	
1 - RTS	1	Jumped
2 - DTR	1	
3 - Casablanca III receives on this pin	1	
4 - GND		
5 - GND		
6 - Casablanca III sends on this pin	0	
7 - DCD	0	
8 - CTS	0	

CN3



Rear panel view of DB9 connector
(From outside of unit).



These are the connector drawings only. The RS232 cable must be a regular RS232 or mouse extender cable wired pin-for-pin.

THETA DIGITAL
Casablanca III HD Owners Manual Addendum
RS232 Protocol and Control Details

This document applies to Casablanca III HD (only) with software version 4xx.

Casablanca III HD Owners Manual Addendum

RS232 Protocol and Control Details

Casablanca III RS232 Control Details

RS232 settings will be user definable to accommodate interfacing with a wide range of control products.

Baud rate	9600
Echo status	2

Baud rate: Maximum number of bits per second. The duration of a single bit is equal to 1 / baud rate.

Echo status: Specifies a "status level" to return to controlling device upon any operating change in Casablanca III. E.g. level 1 will return current mode, input, master level. Level 2 will return level 1 plus additional parameters, etc.

The above setting for Baud Rate and Echos is to be adjusted in the Set Up Menu.

Communication:

The parameters for RS232 communication will default to 8 bits, 1 stop bit and no parity.

All values in this document are in Decimal.

All commands will follow the format:

<Header><Command Identifier><Argument 1>< Argument 2>< Argument 3>
where:

<Header> = <254><236>

<Command identifier> = <byte>

< Argument 1> = <byte>

< Argument 2> = <byte>

< Argument 3> = <byte>

Each command will be able to access the system configuration directly, eliminating the need to navigate through multiple layers of menuing to reach a given item.

Input names and jack names can be read and changed via the RS232 port. This is useful when displaying this information on a touch screen panel or other device, to keep Casablanca III and the device synchronized.

Special Commands:

To increment the master volume from any menu: <header> 4 20 3 9 (values are decimal).

To decrement the master volume from any menu: <header> 4 21 3 9 (values are decimal).

To set a specific master volume level from any menu: <header> 1 9 3 x, where x = the volume level [0 -73] (values are decimal).

Casablanca III HD Owners Manual Addendum

RS232 Protocol and Control Details

This document is divided into several sections to facilitate ease of use when looking up values. There is a separate chart for Input Variables, or variables for parameters that are stored by Input. There is another chart for Global Variables. As such there are tables for Status levels, Menus, Character Maps and other Parameters.

Below are some examples of using the command format. These examples will show how and where to look up values.

Example 1:

To Take the Casablanca III out of standby:

Header	Command	Argument 1	Argument 2	Argument 3
254 236	4	14	2	0

All entries from this command string were obtained from the Command List on page 5 of this document.

Example 2:

To select Input # 3:

Header	Command	Argument 1	Argument 2	Argument 3
254 236	4	5	3	0

-All entries from this command string were obtained from the Command List on page 5 of this document.

Example 3:

To change the front center level to +2, for the currently selected input:

Header	Command	Argument 1	Argument 2	Argument 3
254 236	1	37	0	2

-Command 1 is used because it is required to change a parameter that is not already listed under the “commands and argument 1’s on the Command List.

-Argument 1’s value was found on the *Input Variables chart*, as indicated under the “Argument 1 description”.

-The Argument 2 was used because this is an Input variable. i.e. a parameter that is stored “by Input”

-Argument 3’s value is the “new value” that is desired for the parameter being edited.

Example 4:

To change the analog tape out source to the coax 3 input jack:

Header	Command	Argument 1	Argument 2	Argument 3
254 236	1	3	1	9

-Command 1 is used because it is required to change a parameter that is not already listed under the “commands and argument 1’s on the Command List.

-Argument 1’s value was found on the *Global Variables chart*, as indicated under the “Argument 1 description”.

-The Argument 2 was used because this is an Global variable. i.e. a parameter that is NOT stored “by Input”

-Argument 3’s value is the “new value” that is desired for the parameter being edited. In the case of Jack names/variable numbers, this data was found on the Jack Variable chart.

Casablanca III Owners Manual Addendum
RS232 Protocol and Control Details – Command List

Command	Description	Argument 1	Argument 1 Description	Argument 2	Argument 2 Desc	Argument 3	Arg 3 Desc
1	Input Variable Change	0-255	Variable Number (see Input Variables chart)	0	Input setting	0-255	New value
1	Global Variable Change	0-255	Variable Number (see Global Variables chart)	1	Global setting	0-255	New value
3	Update Display	1	Menu LEDs	0		0	
		2	Menu Parameters	0		0	
		3	Menu Display	0		0	
		4	Re-display whole menu	0		0	
4	Do Action						
		5	Select Input	1-12	Input number.	0	
		6	User Mute	0	Toggle mute.	0	
				1	Mute.	0	
				2	Unmute.	0	
		8	Go To Menu	0-255	Menu # Menu Chart.	0-255	time at new menu
		9	Go To Menu W/Password Check	0-255	Menu # Menu chart.	0-255	time at new menu
		12	Source change.	0	Cycle source.	0	
				1-6	Set source.	0	
		14	Power main.	0	Cycle standby.	0	
				1	Put unit into standby.	0	
				2	Take out of standby.	0	
		15	Power remote	0	Cycle remote power.	0	
		17	Mode select	0	Matrix	0	
			(Note: If in input select menu,	1	Special Matrix	0	
			this command should be followed	4	Stereo	0	
			by "03 04 00 00" to update the	5	Analog Direct	0	
			display.)	6	Analog Matrix	0	
				7	Mono	0	
				8		0	
				9		0	
				10		0	
				11	Pro Logic IIx Movie	0	
				12	Pro Logic IIx Music	0	
				13	Pro Logic IIx Mono Mx	0	
				14	DTS NEO:6 Cinema	0	
				15	DTS NEO:6 Music	0	
		20	Input Variable, Specified, Increment	0	Input setting	0-255 From Input Variable chart.	Variable Number
		20	Global Variable Specified, Increment	1	Global setting	0-255 From Global Variable chart	Variable Number

Casablanca III Owners Manual Addendum
RS232 Protocol and Control Details – Command List

Command	Description	Argument 1	Argument 1 Description	Argument 2	Argument 2 Desc	Argument 3	Arg 3 Desc
		20	Internal Variable Specified, Increment	3	Internal setting	9	Master Volume
		21	Input Variable Specified, Decrement	0	Input setting	0-255 From Input variable chart.	Variable Number
		21	Global Variable Specified, Decrement	1	Global setting	0-255 From Global variable chart	Variable Number
		21	Internal Variable Specified, Decrement	3	Internal setting	9	Master Volume
		26	Variable, Input, Set Value	0-255	Variable Number	0-255	New Value
		36	Return To Previous Menu	0-4	# of menus to go back		
5	Get Input variable value	0-255	Input Variable Number (see Input Variable chart).	0	Input setting	0	
5	Get Global variable value	0-255	Global Variable Number (see Global Variable chart).	1	Global setting	0	
6	Return status	0-4	Return specified status level.	0		0	
11	Simulate Keypress	0	None	0		0	
		1	1	0		0	
		2	2	0		0	
		3	3	0		0	
		4	4	0		0	
		5	5	0		0	
		6	6	0		0	
		7	A/D	0		0	
		8	Mute	0		0	
		9	Mode	0		0	
		10	Tape Out	0		0	
		11	Setup	0		0	
		12	Balance	0		0	
		13	Display IR	0		0	
		14	Power Main	0		0	
		15	Up	0		0	
		16	Down	0		0	
		17	Power Remote	0		0	
		18	Status	0		0	
		19	Left	0		0	
		20	Right	0		0	
		21	Phase	0		0	
		22	Select Up	0		0	

Casablanca III Owners Manual Addendum
RS232 Protocol and Control Details – Command List

Command	Description	Argument 1	Argument 1 Description	Argument 2	Argument 2 Desc	Argument 3	Arg 3 Desc
		23	Select Down	0		0	
		25	Power Standby	0		0	
		26	Power Activate	0		0	
12	Read Serial Number ** See note #1	0		0		0	
17	Return OS version ** See note #3	0		0		0	
25	Execute Macro ** See note #4	0	Copy Current Input Settings	1-12	Input to copy to	0	
		1	Copy Current Speaker Settings	1-12	Input to copy to	0	
		2	Restore factory default settings	0	To Current Input	0	
				1	To All Inputs	0	
				2	To Global Settings	0	
				3	To Input and Jack Names	0	
				4	To Everything	0	

** Note 1: After sending command Casablanca will return 6 ASCII bytes representing the serial number.

** Note 2: After sending command Casablanca, Casablanca will return 121 bytes plus a checksum.

** Note 3: Returns 2 bytes containing a leading 0 and the version number.

** Note 4: Casablanca will return " 01" upon completion of the macro. All macro commands should be followed with a "Go To Menu" command, with the desired menu number as argument 1. This is because macros internally alter the current menu number.

Casablanca II Owners Manual Addendum
RS232 Protocol and Control Details – Input Variable Chart

Input Variables:

Variable #	Variable Name
0	CENTER_CONFIG
1	LR_BW_LOP_FREQ
2	CEN_PF_FREQ
3	CEN_PF_SLOPE
4	CEN_PF_LOP_PHASE
5	CEN_BW_HIP_SLOPE
6	CEN_BW_HIP_FREQ
7	CENTER_LOPASS_TO
9	LR_CONFIG
10	CENTER_TYPE
11	LR_PF_FREQ
12	LR_PF_SLOPE
13	LR_PF_LOP_PHASE
14	LR_BW_HIP_SLOPE
15	LR_BW_HIP_FREQ
16	SUR_CONFIG
17	SUR_PF_FREQ
18	SUR_PF_SLOPE
19	LR_LR_SLOPE
20	SUR_PF_LOP_PHASE
21	LR_LR_LOP_PHASE
22	SUR_BW_HIP_SLOPE
23	SUR_BW_HIP_FREQ
24	DELAY_LEFT
25	DELAY_REAR_LEFT
26	DELAY_REAR_RIGHT
27	DELAY_CENTER
28	DELAY_RIGHT
29	DELAY_SUB_1
30	CEN_BW_LOP_FREQ
31	CEN_BW_LOP_SLOPE
32	CEN_BW_LOP_PHASE
33	CEN_LR_FREQ
34	CEN_LR_SLOPE
35	DD_ADD_SPKRS

Variable #	Variable Name
36	LEVEL_LEFT
37	LEVEL_CENTER
38	LEVEL_RIGHT
39	LEVEL_REAR_LEFT
40	LEVEL_REAR_RIGHT
41	LEVEL_SUB_1
42	SEARCH_6_VIDEO
43	LEVEL_PHTM_SUR
44	DTS_ADD_SPKRS
45	PL2X_PANORAMA
46	PL2X_CTR_WIDTH
47	NEO6_CTR_GAIN
48	SIX_SHOOTER
49	
50	
51	
52	
53	DD_2CH_MODE_ENC
54	DD_COMPRESSION
55	DD_COMP_HIGH
56	DD_COMP_LOW
57	DD_DIALOG_NORM
58	DD_LFE_GAIN
59	DD_DELAY_CENTER
60	DD_LEVEL_CENTER
61	SUB2_FULL_XOVER
62	DD_LEVEL_SUR
63	DTS_LFE_GAIN
64	DTS_DELAY_CENTER
65	DTS_LEVEL_CENTER
66	DTS_DELAY_SUR
67	DTS_LEVEL_SUR
68	MODE_DEFAULT
69	CEN_LR_LOP_PHASE
70	LFE_PHASE

Variable #	Variable Name
71	SUB3_FULL_XOVER
72	SEARCH_1
73	SEARCH_2
74	SEARCH_3
75	SEARCH_4
76	SEARCH_5
77	SEARCH_6
78	
79	
80	DD_EX_DECODE (+SPKR)
81	VFD_BRIGHTNESS
82	NAME_VFD
83	NAME_OSD
84	OSD_BACKGROUND_COLOR
85	OSD_LEFT_EDGE
86	OSD_TOP_EDGE
87	OSD_CONFIG
88	OSD_DISPLAY_TIME
89	STATUS_MODE
90	STATUS_INPUT
91	STATUS_TAPE
92	STATUS_LEVEL
93	STATUS_EQ
94	STATUS_PHASE
95	STATUS_SOURCE
96	LR_LR_FREQ
97	POST_PROCESS
98	LR_BW_LOP_SLOPE
99	SUBS_NUMBER
100	SUB1_FULL_XOVER
101	
102	
103	
104	
105	

Casablanca II Owners Manual Addendum
RS232 Protocol and Control Details – Input Variable Chart

Variable #	Variable Name
106	LR_BW_LOP_PHASE
107	SOURCE_NOISE1_NOISEALL
108	SUR_BW_LOP_FREQ
109	SUR_BW_LOP_SLOPE
110	SUR_BW_LOP_PHASE
111	SUR_LR_FREQ
112	SUR_LR_SLOPE
113	SUR_LR_LOP_PHASE
114	SUB4_FULL_XOVER
116	CENTER_SPREAD
117	DD_DELAY_SURROUND
119	SIDE_CONFIG
120	SURROUND_CENTER
122	LR_TYPE
123	SURROUND_TYPE
124	LEVEL_SIDE_LEFT
125	LEVEL_SIDE_RIGHT
126	LEVEL_REAR_CENTER or SUB5
127	LEVEL_SUB_2
128	LEVEL_SUB_3
129	LEVEL_SUB_4
130	DELAY_REAR_CENTER or SUB 5
131	DELAY_SIDE_LEFT
132	DELAY_SIDE_RIGHT
133	DELAY_SUB_2

Variable #	Variable Name
134	DELAY_SUB_3
135	DELAY_SUB_4
138	STATUS_SAMPLE_RATE
139	JACK_SEARCH
140	DELAY_MASTER
141	DD_2CH_MODE_NENC
142	SURC_CONFIG
143	SURC_BW_HIP_FREQ
144	SURC_BW_HIP_SLOPE
145	SURC_BW_LOP_FREQ
146	SURC_BW_LOP_SLOPE
147	SURC_BW_LOP_PHASE
148	SURC_LR_FREQ
149	SURC_LR_LOP_PHASE
150	SURC_LR_SLOPE
151	SURC_PF_FREQ
152	SURC_PF_LOP_PHASE
153	SURC_PF_SLOPE
154	SURC_TYPE
156	LEVEL_PHTM_FRONT_CENTER
157	LEVEL_PHTM_SUR_CENTER
158	SUB5_FULL_XOVER
159	LEVEL_SUB_5
160	DELAY_SUB_5

Casablanca II Owners Manual Addendum
RS232 Protocol and Control Details – Global Variable Chart

Global Variables:

Variable #	Variable Name
0	TAPE_FOLLOW_INP
1	BALANCE_CLEAR
2	BALANCE_ANALOG_INPUT_LEVEL
3	ANALOG_TAPE_OUT
5	LEVEL_MASTER_INITIAL
6	PHASE
7	BALANCE_EQ
8	MAIN_TIME
9	CURSOR_VFD
11	MAIN1_TYPE
13	VOLUME_FAST
14	MAIN2_TYPE
15	LEVEL_MAX
16	TAPE_DIGITAL_SOURCE
17	REMOTE_PULSE_DURATION
18	TAPE_OUT_DIGITAL
19	TAPE_OUT_VIDEO
20	MUTE_LEVEL
21	MUTE_TRIGGER

Variable #	Variable Name
22	RS232_BAUD_RATE
24	RS232_ECHO_STATUS
27	VOLUME_SLOW
32	MAIN_OFF_SEQUENCE
33	REMOTE_TYPE
34	MAIN3_TYPE
35	BALANCE_L_R
36	BALANCE_F_R
37	BALANCE_CENTER
38	BALANCE_SUBS
39	ANALOG_TAPE_OUT
40	ANALOG_LEVEL_1
41	ANALOG_LEVEL_2
42	ANALOG_LEVEL_3
43	ANALOG_LEVEL_4
44	ANALOG_LEVEL_5
45	ANALOG_LEVEL_6
50	MSG_MODE
57	IDLE_TIMEOUT

Casablanca III Owners Manual Addendum
RS232 Protocol and Control Details – Status Levels Chart

Status Levels:

The RS232 can be set to automatically send changes to the RS232 port. This is done by selecting a "status level" in the RS232 menu, which means if any parameter changes, that level's bytes will be sent to the port. This is useful for monitoring master level, input and the like when the user has access to both the Casablanca III and the touch-panel controller, to keep them synchronized.

Status level 0:	No status returned.		
Status level 1:			
Byte #	Byte Description	Value	Value Description
1	Input	1-12	Input Number
2	Jack Selected	1-23	Currently Selected Jack, see parameter "Input_Jacks_Alterable" for list.
3		1-8	Currently selected video jack.
4	Master level	0-73	
5	Mode	0	Matrix
		1	Special Matrix
		4	Stereo
		5	Analog Direct
		6	Analog Matrix
		7	Mono
		8	
		9	
		10	
		11	Pro Logic IIx Movie
		12	Pro Logic IIx Music
		13	Pro Logic IIx Mono Mx
		14	DTS NEO:6 Cinema
		15	DTS NEO:6 Music
6	Standby	0	Unit in standby.
		1	Unit not in standby.
Status level 2:	All status level 1 bytes plus:		
7	lock	0	no locked
		1	locked
8	sample rate	0	32 KHz
		1	44.1KHz
		2	48KHz
		3	xx
		4	xx
		5	96KHz
9	user mute	0	Mute not activated.
		1	Mute activated.

Casablanca III Owners Manual Addendum
RS232 Protocol and Control Details – Status Levels Chart

Status Level 2 Con't

Byte #	Byte Description	Value	Value Description
10	Display brightness	0	full
		1	3/4
		2	1/2
		3	1/4
		4	off
11	Analog Level	0	Clip
		1	-6 through -1
		3	-12 through -7
		7	-18 through -11
		15	Input level below -18
12	Remote power	0-60	bit 2 = remote
			bit 3 = main 1
			bit 4 = main 2
			bit 5 = main 3
13	Current menu	0-x	Menu number.

Casablanca III Owners Manual Addendum
RS232 Protocol and Control Details – Status Levels Chart

Status level 3 All Status Level 1 & 2 bytes plus:

Byte#	Byte Description
14	TAPE_FOLLOW_INP
15	BALANCE_CLEAR
16	BALANCE_ANALOG_INPUT_LEVEL
17	TAPE_OUT
19	LEVEL_MASTER_INITIAL
20	PHASE
21	BALANCE_EQ
22	MAIN_TIME
23	CURSOR_VFD
24	SYS_FRCEN_FRSUB
25	MAIN1_TYPE
26	SYS_BAL3_SUB4_SUB5
27	VOLUME_FAST
28	MAIN2_TYPE
29	LEVEL_MAX
30	TAPE_DIGITAL_SOURCE
31	REMOTE_PULSE_DURATION
32	TAPE_OUT_DIGITAL
33	TAPE_OUT_VIDEO
34	MUTE_LEVEL

Byte#	Byte Description
35	MUTE_TRIGGER
36	RS232_BAUD_RATE
38	RS232_ECHO_STATUS
41	VOLUME_SLOW
46	MAIN_OFF_SEQUENCE
47	REMOTE_TYPE
48	MAIN3_TYPE
49	BALANCE_L_R
50	BALANCE_F_R
51	BALANCE_CENTER
52	BALANCE_SUBS
53	ANALOG_TAPE_OUT
54	ANALOG_LEVEL_1
55	ANALOG_LEVEL_2
56	ANALOG_LEVEL_3
57	ANALOG_LEVEL_4
58	ANALOG_LEVEL_5
59	ANALOG_LEVEL_6
64	MSG_MODE

Casablanca III Owners Manual Addendum
RS232 Protocol and Control Details – Status Levels Chart

Status level 4: All status level 1-3 bytes plus all current input variable bytes:

Byte#	Byte Description
65	CENTER_CONFIG
66	LR_BW_LOP_FREQ
67	CEN_PF_FREQ
68	CEN_PF_SLOPE
69	CEN_PF_LOP_PHASE
70	CEN_BW_HIP_SLOPE
71	CEN_BW_HIP_FREQ
72	CENTER_LOPASS_TO
74	LR_CONFIG
75	CENTER_TYPE
76	LR_PF_FREQ
77	LR_PF_SLOPE
78	LR_PF_LOP_PHASE
79	LR_BW_HIP_SLOPE
80	LR_BW_HIP_FREQ
81	SUR_CONFIG
82	SUR_PF_FREQ
83	SUR_PF_SLOPE
84	LR_LR_SLOPE
85	SUR_PF_LOP_PHASE
86	LR_LR_LOP_PHASE
87	SUR_BW_HIP_SLOPE
88	SUR_BW_HIP_FREQ
89	DELAY_LEFT
90	DELAY_REAR_LEFT
91	DELAY_REAR_RIGHT
92	DELAY_CENTER
93	DELAY_RIGHT
94	DELAY_SUB_1
95	CEN_BW_LOP_FREQ
96	CEN_BW_LOP_SLOPE
97	CEN_BW_LOP_PHASE
98	CEN_LR_FREQ
99	CEN_LR_SLOPE

Byte#	Byte Description
100	DD_ADD_SPKRS
101	LEVEL_LEFT
102	LEVEL_CENTER
103	LEVEL_RIGHT
104	LEVEL_REAR_LEFT
105	LEVEL_REAR_RIGHT
106	LEVEL_SUB_1
107	SEARCH_6_VIDEO
108	LEVEL_PHTM_SURROUND
109	DTS_ADD_SPKRS
110	PL2X_PANORAMA
111	PL2X_CTR_WIDTH
112	NEO6_CTR_GAIN
113	SIX_SHOOTER
114	
115	
116	
117	
118	DD_2CH_MODE_ENC
119	DD_COMPRESSION
120	DD_COMPRESSION_HIGH
121	DD_COMPRESSION_LOW
122	DD_DIALOG_NORMALIZATION
123	DD_LFE_GAIN
124	DD_DELAY_CENTER
125	DD_LEVEL_CENTER
126	SUB2_FULL_XOVER
127	DD_LEVEL_SURROUND
128	DTS_LFE_GAIN
129	DTS_DELAY_CENTER
130	DTS_LEVEL_CENTER
131	DTS_DELAY_SURROUND
132	DTS_LEVEL_SURROUND
133	MODE_DEFAULT

Byte#	Byte Description
134	CEN_LR_LOP_PHASE
135	LFE_PHASE
136	SUB3_FULL_XOVER
137	SEARCH_1
138	SEARCH_2
139	SEARCH_3
140	SEARCH_4
141	SEARCH_5
142	SEARCH_6
143	
144	
145	DD_EX_+SPKR
146	VFD_BRIGHTNESS
147	NAME_VFD
148	NAME_OSD
149	OSD_BACKGROUND_COLOR
150	OSD_LEFT_EDGE
151	OSD_TOP_EDGE
152	OSD_CONFIG
153	OSD_DISPLAY_TIME
154	STATUS_MODE
155	STATUS_INPUT
156	STATUS_TAPE
157	STATUS_LEVEL
158	STATUS_EQ
159	STATUS_PHASE
160	STATUS_SOURCE
161	LR_LR_FREQ
162	POST_PROCESS
163	LR_BW_LOP_SLOPE
164	SUBS_NUMBER
165	SUB1_FULL_XOVER
166	
167	

Status Level 4 Con't

Byte#	Byte Description
168	SEARCH_4_VIDEO
169	SEARCH_3_VIDEO
170	SEARCH_5_VIDEO
171	LR_BW_LOP_PHASE
172	SOURCE_NOISE1_NOISEALL
173	SUR_BW_LOP_FREQ
174	SUR_BW_LOP_SLOPE
175	SUR_BW_LOP_PHASE
176	SUR_LR_FREQ
177	SUR_LR_SLOPE
178	SUR_LR_LOP_PHASE
179	SUB4_FULL_XOVER
182	DD_DELAY_SURROUND
185	SURROUND_CENTER
186	AUTO_SEARCH
187	LR_TYPE
188	SURROUND_TYPE
189	LEVEL_SIDE_LEFT
190	LEVEL_SIDE_RIGHT
191	LEVEL_REAR_CENTER
192	LEVEL_SUB_2
193	LEVEL_SUB_3
194	LEVEL_SUB_4
195	DELAY_REAR_CENTER
196	DELAY_SIDE_LEFT
197	DELAY_SIDE_RIGHT

Byte#	Byte Description
198	DELAY_SUB_2
199	DELAY_SUB_3
200	DELAY_SUB_4
203	STATUS_SAMPLE_RATE
204	JACK_SEARCH
205	DELAY_MASTER
206	DD_2CH_MODE_NENC
207	SURC_CONFIG
208	SURC_BW_HIP_FREQ
209	SURC_BW_HIP_SLOPE
210	SURC_BW_LOP_FREQ
211	SURC_BW_LOP_SLOPE
212	SURC_BW_LOP_PHASE
213	SURC_LR_FREQ
214	SURC_LR_LOP_PHASE
215	SURC_LR_SLOPE
216	SURC_PF_FREQ
217	SURC_PF_LOP_PHASE
218	SURC_PF_SLOPE
219	SURC_TYPE
221	LEVEL_PHTM_FRONT_CENTER
222	LEVEL_PHTM_SUR_CENTER
223	SUB5_FULL_XOVER
224	LEVEL_SUB_5
225	DELAY_SUB_5

Casablanca III Owners Manual Addendum
RS232 Protocol and Control Details – Menu Chart

Menus:

Menu #	Menu Description
0	INPUT_SELECT_1
1	MODE_1
2	MODE_2
3	TAPE_OUT
4	SETUP_GLOBAL_1
5	SETUP
6	INPUT_SELECT_2
7	SETUP_INPUT_1
8	SETUP_INPUT_2
9	SETUP_INPUT_SPEAKER_CONFIGURATION
10	SETUP_INPUT_CONFIG_LEFT_RIGHT
11	SETUP_INPUT_CONFIG_CENTER_1
13	SETUP_INPUT_CONFIG_SURROUNDS
14	CONFIG_SUBS
15	
16	
17	DELAYS_1
19	SETUP_INPUT_SEARCH_ORDER
20	
21	
22	
23	SETUP_STATUS_DISPLAY_1
24	SETUP_INPUT_MISCELLANEOUS_1
25	SETUP_REMOTE_POWER
28	STATUS_DOLBY_DIGITAL_1
29	SETUP_DTS_1
30	STATUS_DTS
31	SETUP_INPUT_3
32	NOT USED
33	MACROS
34	MACROS_1_1
38	STATUS
39	RS232
41	PHASE
42	SETUP_INPUT_POST_PROCESS
44	SETUP_DOLBY_DIGITAL_2
45	MACROS_1_2

Menu #	Menu Description
46	SETUP_NAMES_DIGITAL_COAX
47	SETUP_INPUT_JACK_NAMES
48	SETUP_NAMES_DIGITAL_MISC_1
49	SETUP_ANALOG_INPUT_LEVELS
50	SETUP_NAMES_ANALOG
51	BALANCE_1
52	BALANCE_2
53	SETUP_NAMES_VIDEO_1
55	CONFIG_LEFT_RIGHT_PHASE_PERFECT
56	CONFIG_LEFT_RIGHT_LINKWITZ_RILEY
57	CONFIG_LEFT_RIGHT_BUTTERWORTH
58	CONFIG_CENTER_PHASE_PERFECT
59	CONFIG_CENTER_LINKWITZ_RILEY
60	CONFIG_CENTER_BUTTERWORTH
61	CONFIG_SURROUNDS_PHASE_PERFECT
62	CONFIG_SURROUNDS_LINKWITZ_RILEY
63	CONFIG_SURROUNDS_BUTTERWORTH
65	MODE_3
67	SETUP_MUTE_VOLUME
68	SETUP_NAMES_DIGITAL_MISC_2
69	LEVELS_MAIN
70	LEVELS_2
72	DELAYS_2
74	SETUP_STATUS_DISPLAY_2
75	SETUP_GLOBAL_2
76	SETUP_INPUT_CONFIG_SURR_CEN
77	CONFIG_SURRC_PHASE_PERFECT
78	CONFIG_SURRC_LINKWITZ_RILEY
79	CONFIG_SURRC_BUTTERWORTH
80	MACROS_INPUT
81	MACROS_SPEAKER
82	MACROS_FACTORY
83	SETUP_NAMES_VIDEO_2
96	SETUP_DOLBY_DIGITAL_3 (EX)
97	SETUP_DTS_2
98	SETUP_DOLBY_DIGITAL_3 (DPLIIX)

Jack Variables

Jack Name	Value
Analog 1	1
Analog 2	2
Analog 3	3
Analog 4	4
Analog 5	5
Analog 6	6
Coax 1	7
Coax 2	8
Coax 3	9
Coax 4	10
Coax 5	11
Coax 6	12
Tos 1	13
Tos 2	14
Glass 1	15
Glass 2	16
AES 1	17
BNC 2	18
Tos 3	19
Glass 4	20
RF1	21
RF2	22
INPUT*	23
OFF**	24


In the Tape Out menu:

*"INPUT" selection means that the tape out menu mirrors the source active on the main system as the user changes from one source to another

**"OFF" means that there will be no source routed to the tape out jack.

Casablanca III Owners Manual Addendum
RS232 Protocol and Control Details

The command to request a status level is 06 0x 00 00, where x= the status level. When this command is issued, there is a 6.7mS delay before the first status byte is received.



The ECHOS parameter in the Casablanca III determines what status levels of data are returned. The diagram below shows all 4 status' levels returned and the delay times between them. Note there is no delay time between status level 1 and 2. In addition, this diagram shows the duration of each status level.

